MULTI CARRIER

HXF 3302



PARTS

UK

6th Edition 2022







IMPORTANT INFORMATION

GreenTec HXF 3302

PARTS 6th Edition – April 2022

<u>NOTICE:</u> Please ensure that this manual is handed to the operator before using the machine for the first time. If the machine is resold the Parts list must be given to the new owner!

The information contained in this Parts list is correct at the time of publication. However, in the course of constant development, changes in specification are inevitable. Should you find the information given in this book different to the machine it relates to please contact the "After Sales Department" for advice.



Merkurvej 25 DK 6000 Kolding Denmark Tel: +45 75553644

Fax: +45 75554243 Email: info@greentec.eu web: www.greentec.eu

© GreenTec Machinery Limited 2016



CONTENTS

Contents

CONTENTS	4
INTRODUCTION	
USEFUL INFORMATION	6
ORDERING PARTS	7
SPARE PARTS	8
Arm system	8
Head angle ram	10
Splitter valve	11
Controlbox with cable	12
Break-Back ram	13
Accumulator	14
Easy Pilot controls	15
ADGT 1368 EL-valve	
Stickers	18



INTRODUCTION

Dear customer!

Your new Greentec machine is constructed with background in more than 20 years experience with tractor mounted machines to maintenance of green areas. This machine is produced by the latest technology and recognized safety regulations, standards and regulations.

We want to make a product available in such a way, that neither the use of the machine during transportation or maintenance of the machine causes any damage or misunderstandings.

This parts list contains information that are important and useful for maintaining your Greentec machine's reliability, dependability and value.

You are welcome to visit our website www.greentec.eu - where the login via the dealer's access gives you the latest updates on instructional and part books on our entire product range.

We hope, you will be pleased with your new Greentec machine.



John Christensen Sales Director Greentec A/S

Greentec's vision is to develop and sell quality machines for the maintenance of green areas, including in agriculture, in industry, at airports and in the local sector. Through innovative product development, we will strive to become a leader in our field.

All machines are developed in a simple and functional design in close cooperation with dealers and end users. It is our goal to cover every need in the market segment with preferably 2 different solutions. In-depth analysis of requirements and serious advice to the customer is offered the best solution, where individual needs can be met through the modularity of the product program. Our goal is also to offer the best possible after sales service, and a quick and efficient spare parts supply.



USEFUL INFORMATION

Before using the machine for the first time, it's the seller's responsibility that the buyer is given this parts list. If the machine is resold, the parts list must be transferred to the new owner.

Please fill out the list below to ensure that the necessary information is at hand when ordering spare parts etc.

Serial No	
Dell'esses lette	
Delivery date	
Dealer	
Tel./ E-mail	



Merkurvej 25 DK 6000 Kolding Danmark Tel: +45 75553644

Fax: +45 75554243
Email: info@greentec.eu
web: www.greentec.eu
Opening hours: Mon-Fri 8-16



ORDERING PARTS

When ordering parts please refer to your parts list to help your dealer with your order.

- Part number and quantity
- Description
- Machine model number
- Serial number of the machine
- Delivery instructions (e.g. next day).

Delivery is normally via carrier direct to your dealer. Please check with your dealer for stock availability and arrangement of dispatch. Ensure you or your dealer has sufficient cover for parts requirement outside factory hours.

Important Note

The information contained in this manual is correct at the time of publication. However, in the course of constant development, changes in specification are inevitable. Should you find the information given in this book different to the machine it relates to, please contact the "After Sales Department" for advice.


Key:

(LH) = Left hand (RH) = Right hand



SPARE PARTS

Arm system




NO.	PART NUMBER	DESCRIPTION	QTY.
1	8351501	Main frame	1
2	8351500	Arm	1
3		See "Break-back ram"	1
4	8352001	Support bolt	3
5	6706003	Pin with handle for break-back ram	1
6	8351004	Lid	1
7	8351502	Head crowd bracket	1



8	8351001	Reinforcement part	1
9	8351002	Reinforcement part (Mirror of item 8)	1
10	8351005	Leg for arm	1
11	8351006	Washer HD	2
12	8351007	Lid (Mirror of item 6)	1
13	8351503	Pin for arm	1
14	8351504	Pin for head crowd bracket	1
15	6310202A	Pin for top link / head angle ram (long)	1
16	6310202	Pin for top link / head angle ram (short)	1
17	8356001	Pin for break-back ram	1
18	8286003	Top link Kat 1/1	1
19	8351008	Leg for main frame	1
20	8351009	Leg for main frame (Mirror of item 19)	1
21		See "Accumulator"	1
22	6706004	Lynch pin	4
23	8354001	Flange bush	4
24	2770449	Nut	3
25	8222002	Bolt	14
26	2770436	Washer	14
27	8142002	Bolt	2
28	8222003	Spring Washer	2
29		See "Head angle Ram" (Option)	1
30	8222012	Bolt	2
31	8222013	Spring Washer	2
32	8351010	Counterweight (Option)	3
33	8352002	Bolt (Option)	1
34	8351003	Angled plate for attachment	2
35	2770409	Lock Nut	2
36	2770517	Facet washer	2
37	8351012	Steel bush	1
38	8362006	Bolt	8
39	8362005	Lock nut	8
40	2770434	Washer	16
41	200104.0	Screw	8
42		See "Stickers"	1




Head angle ram



NO.	PART NUMBER	DESCRIPTION	QTY.
1	8283007	Head angle ram	1
3	6703002	Adapter with restrictor	2
4	6703003	Seal	2



Splitter valve



NO.	PART NUMBER	DESCRIPTION	QTY.
1	8351506	Bracket	1
2	6703014-40	Flowregulator	1
3	8290032	Nipple	1
4	8283010	Nipple	6
5	6703024	NIpple	2
6	8143005	Bounded seals	1
7	6703010	Bounded seals	2
8	R12	Plug	1
9	R14	Plug	2
10	R34	Plug	1
11	931080852	Bolt	1
12	2770416	Nut	2
13	2770412	Lock Nut	4
14	8362011	Washer	2
15	200109.0	Bolt	1
16	81823005	Nipple	1



Controlbox with cable






ITEM NO	PART NUMBER	DESCPIPTION	QTY
1	6708004	Controlbox	1
2	6702204	Cable for valve	1
NS	6708004.2	Extension cabel 6Mtr	1




Break-Back ram



NO.	PART NUMBER	DESCRIPTION	QTY.
1	8283017	Break-Back ram	1
2	6703013	Breather	1
3	6703012	Banjo bolt	1
4	6703011	Banjo	1
5	6703003	Seal	2




Accumulator



NO.	PART NUMBER	DESCRIPTION	QTY.
1	8351011	Bracket	1
2	6703005	Accumulator	1
3	6702005	Nut	1
4	6703009	Reduction	1
5	6703010	Seal	1
6	6703006	T-nipple	1
7	8143005	Seal	2
8	6703007	Mini-Mesh	1
9	8222006	Bolt	2
10	2770436	Facet washer	2
11	2770412	Nut	2
12	6703008	Adapter female	1




Easy Pilot controls



No.	PART NUMBER	DESCRIPTION	QTY.
1	157B6709	Priority module (no. is stamped in one end)	1
	157B6200	Motor module	1
	157B6100	Work tool module (no. is stamped in one end)	1
2	157B2018	End lid	1
3	157B5010	End lid – pressure (no. is stamped in one end)	1
4	157B3999	Seal kit for mechanical part	1
5	157B4997	Seal kit for electric part	1
6	157B8003	Seal kit Sandwich (incl. bolt & nuts)	1
7	157B3173	House for mechanical control Cpl. incl. Pos. 4	1
8	157B4216	Electric-module 12V incl. pos. 5	1
	Following are not shown:		
	157B7000	Spool DA 10 L	
	157B7103	Spool DA 65 L open	



ADGT 1368 EL-valve





NO.	PART NUMBER	DESCRIPTION	QTY.
1	6702261	Valve (from serielnbr. 222843816)	1
2	81823025	Plug	2
3	6703010	Seal	2
4	6703024	Nipple	1
5	8290036	Nipple	2
6	8283010	Nipple	2
7	8283009	Nipple	1
8	8283011	Seal	2
9	6703003	Seal	2
10	81823010	Nipple	2
11	8283013	Nipple	1
12	R34	Plastic cap	1
13	8362011	Washer	2
14	2770402	Bolt	2
15	R12	Plastic cap	1
16	81823005	Nipple	2
17	8290037	Nipple	1
18	6701988	Plug	1



Stickers







8770322 Smørring - 50 x 24 mm



HXF3302 advarselsmærker - 266 x 112 mm

HXF3302 klistermærke top - 545 x 115 mm



HXF3302 klistermærke bund - 545 x 115 mm



8770298 - 45 x 112 mm





HXF3302 KITS

NO.	PART NUMBER	DESCRIPTION	QTY.
1	HXF3302KITS	Sticker kit Cpl	1

